

**STOP! PLEASE READ BEFORE INSTALLING
FIRE EXTINGUISHERS IN THE CABINETS**

Extinguishers For These Cabinets

Cosmic 2-1/2, 5E, 6E, 10 (Model FE10A only)
Galaxy 2-1/2, 5, 5-1/2, 6, 10
Mercury 2-1/2, 5

Bubble Installation



1. Lay the SMB Series cabinet on a flat surface and install the acrylic bubble.
2. Center the acrylic bubble in the cabinet door opening.
3. Using the metal angle brackets and screws supplied, screw each metal bracket in the preset holes at just outside the corner edge of the bubble.
4. This cabinet will support most 5 lb. and 10 lb. fire extinguishers.

Extinguisher Alignment and Installation

NOTE: Alignment of the fire extinguisher in the cabinet is important to the door operation and aesthetics of the installation. It is recommended to ALIGN the extinguisher and mounting bracket in the cabinet BEFORE INSTALLING the SMB Series cabinet on the wall.

5. Lay the SMB Series cabinet on a flat surface. With the extinguisher mounting bracket (J-Hook or Mark Bracket) attached to the fire extinguisher, lay the extinguisher & bracket in the cabinet tub.
6. Align the extinguisher & bracket side to side and top to bottom for the desired placement.
7. Gently close the bubble door to insure the bubble or door frame does not interfere or hinder the complete opening or closing of the cabinet door. Note: A 10 lb. extinguisher will be a tight fit and will be less maneuverable for adjustments.
8. If either the bubble or door frame interferes with the door operation, **ADJUST** the extinguisher and bracket in the direction that will best eliminate this condition.
9. Once the alignment is set, open the cabinet door. Using a **pencil**, mark or outline the bracket location in the cabinet.
10. Remove the extinguisher and bracket from the tub. Detach the extinguisher bracket from the extinguisher.
11. Place the extinguisher bracket back inside the tub where its outline was marked and mark the bracket's mounting holes with a pencil.
12. Remove the bracket and **DRILL** the required holes through cabinet's backside for the appropriate mounting screws, bolts or other hardware. Remove/Eraser pencil marks from cabinet wall.
13. Repeat Step 7 to insure alignment remains intact and the door operates without interference.
14. Install the mounting bracket in the cabinet before or after the cabinet is installed pending the installation area conditions or requirements.
15. After the cabinet installation is completed, mount the extinguisher on its bracket and check again for any interference with the door's operation. Adjust as needed.

**Extinguishers MUST BE MOUNTED on the SMB Series cabinet tub wall with a bracket.
DO NOT SET THE FIRE EXTINGUISHER "Free Standing" ON THE CABINET FRAME.**

 JL INDUSTRIES	 <small>www.activarcp.com</small>	Distributor:	Quantity:
		Contractor:	Approved By:
		Model #:	Architect:
		Project:	Date:
<p>HEADQUARTERS & CUSTOMER SERVICE: 4450 WEST 78TH ST CIRCLE, BLOOMINGTON, MN 55435-5416 PH: 800-554-6077 FAX: 952-835-2218 EMAIL: SALES@JLINDUSTRIES.COM WWW.ACTIVARCPG.COM ACPG SOUTHEAST (THOMAS ENTERPRISES): FT MEYERS, FL ACPG WEST COAST (SAMSON PRODUCTS): COMMERCE, CA ACPG WAREHOUSES: DALLAS TX, LANCASTER PA, ATLANTA GA , CHICAGO IL, SEATTLE WA 2-2-2011</p>			