

PAINT RECOATING SUGGESTIONS | 141-600

For cold rolled, galvanized, galvanized steel and aluminum products

Powder Coat Paint Recoating Suggestions:

1. Abrade the entire paint surface with an abrasive pad or sandpaper to a dull sheen to ensure the topcoat sticks.
2. It is recommended that all parts be cleaned well, before any paint is applied in the field. After abrading the surface, the parts should be wiped with an alcohol-based product which will clean and help reopen the surface for the best adhesion of the topcoat. Be sure to read the product directions prior to use.
3. Use a high-quality paint that is suitable for metal. Activar Construction Products Group, Inc. cannot accept liability for the performance of specific brands of paint.

Prime Coat Repainting Suggestions:

1. Clean or scuff primed surface to remove any grease or contamination present on surface.
2. Solvent wipe with acetone or similar solvent to improve intercoat adhesion.
3. If solvent wiping is impractical, lightly scuff sand and remove all dusts that may inhibit adhesion.
4. Topcoat with high quality 100% acrylic latex or oil-based coatings. Primed surface will also accept coatings with strong solvents such as 2K polyurethanes when cure. Activar Construction Products Group, Inc. cannot accept liability for performance of specific brands of paint.



ACTIVAR CONSTRUCTION PRODUCTS GROUP INC.

9702 Newton Ave S. Bloomington, MN 55431 | Many Locations Nationwide

800-554-6077

sales@activarcpg.com

www.activarcpg.com

PAINT RECOATING SUGGESTIONS
141-600