



## General Maintenance Instructions for Metal Finishes

1. Periodically check the fasteners and tighten if necessary. The fasteners should not loosen regularly; if they do, there is an installation problem that should be resolved.
2. Clean the product routinely by following the cleaning instructions below.

### Finish Cleaning Instructions

**CAUTION:** Always try the recommended procedure in a small inconspicuous spot prior to treating the entire article to verify it works on your particular application and you are satisfied with the results.

**NOTE:** Frequent cleaning extends the life of all finishes.

US3	Polished & lacquered brass	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US3NL	Polished unlacquered brass	Use a soft cloth and a good metal cleaner. We recommend Mr. Metal by Northern Labs.
US4	Satin finish & lacquered brass	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US9	Polished & lacquered bronze	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US10	Satin finished & lacquered bronze	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US10B	Oxidized & oiled bronze	Use a soft cloth and a paste furniture wax. Buff lightly so as not to remove the dark oxide coating where it remains.
US26	Polished chrome plated	Use a soft cloth and a good metal cleaner. We recommend Mr. Metal by Northern Labs.
US26D	Satin chrome plated	Use a soft cloth and a good metal cleaner. We recommend Mr. Metal by Northern Labs.
US28	Anodized aluminum	Use a soft cloth and mild soap and water.
313/315	Dark bronze or black anodized aluminum	Use a soft cloth and mild soap and water.
US32	Polished stainless steel	Use a soft cloth and a good metal cleaner. We recommend Mr. Metal by Northern Labs.
US32D	Satin stainless steel	Use a soft cloth and a good metal cleaner. We recommend Mr. Metal by Northern Labs. For more information about stainless steel see separate page.
US3LIFETIME	Brass	Use a soft cloth and mild soap and water. Use a soft cloth and a good metal cleaner.

**WARRANTY:** All products are warranted to be free of defects in material and workmanship for the period of one (1) year from date of shipment. We reserve the right to replace or repair any product found defective within this period. No other warranty expressed or implied is valid.